

JOINT FUJI Products Catalog for TOYOTA

STOCK NO.	PART NO.	DESCRIPTION
FTH-222A	04371-35030/31	UNIVERSAL JOINT KIT
FTL-221	04371-36010/11	- DO -
FTL-222	04371-36020/21	- DO -
FTL-222	04371-36030	- DO -
FTL-221	04371-60010	- DO -
FTL-223	04371-60020	- DO -
FTL-302	04434-60010	FRONT AXLE OVERHAUL KIT
FTL-303	04434-60011	- DO -
FTL-302A	04434-60012/15/20	- DO -
FTL-302B	04434-60030	- DO -
FTL-302C	04434-60040	- DO -
FTL-302D	04434-60050	- DO -
FTL-302E	04434-60060	- DO -
FTL-302F	04434-60070	- DO -
FTL-336	04445-60020	POWER STEERING KIT
FTL-336A	04445-60030	- DO -
FTL-336B	04445-60040	- DO -
FTL-401	04453-60010/11	STG. CENTER ARM KIT
FTL-402	04453-60020/21	- DO -
FTL-403	04453-60020B	- DO -
FTL-902	13201-38011	CONNECTING (13201-35020)
FTC-901	13201-39015	- DO - RB20#
FTC-901A	13201-39015-EX	- DO - W/OUT METAL RB20#
FTL-903	13201-48010	- DO -
FTL-905	13201-56010/20	- DO - (13201-59045)
FTL-906	13201-58010	- DO - (13201-59035)
FTL-901	13201-60010/11	- DO -
FTL-904	13201-68010	- DO -
FTL-915	13265-39025K	BOLT NUT KIT FOR CON. ROD
FTL-912	13265-48010K	- DO -
FTL-914	13265-58010K	- DO -
FTL-913	13265-59015K	- DO -
FTL-911	13265-60011K	- DO -
FTL-921B	13434-35010	SPLINE, OIL PUMP DRIVE (22R)
FHC-921C	13434-38010	SPLINE , OIL PUMP DRIVE
FTH-926	13503-54030/40	IDLER GEAR (2L, 3L, 2LT.)

STOCK NO.	PART NO.	DESCRIPTION
FTH-921A	13519-54010/11	SPLINE, OIL PUMP DRIVE (L)
FTH-921B	13519-54085/40	- DO - (2L, 3L)
FTL-921	13519-56010	- DO -
FTL-921A	13519-68010	- DO - (2H)
FTH-501	13566-54010	GUIDE PLATE
FTH-931	13750-71010/20	LIFTER VALVE
FTL-935	13751-31020	LIFTER, VALVE (12R)
FTL-935	13751-44030	- DO - (5R)
FTL-935	13751-47010/11	- DO -
FTL-936	13751-54010	- DO - (2L, 3L, 1HZ, HZJ)
FTL-931	13751-56010	- DO - (DG, DL, B)
FTL-931	13751-56011/12	- DO - (B, 3B)
FTL-932A	13751-56020	- DO - (3B, 3TB)
FTL-933	13751-60010/11	LIFTER, VALVE (F,2F)
FTL-933	13751-60020/21	- DO - (F, 2F)
FTL-933	13751-61010	- DO - (2F) 13751-60010
FTL-936A	13751-61020	- DO - (3F)
FTL-936C	13751-64011	- DO -
FTL-936B	13751-66020	- DO - (1FZ)
FTL-937A-02	13753-17090	SHIM, LIFTER (37XT=2.35) 1HZ, 1PZ
FTL-937A-01	13753-17040	- DO - (37XT=2.40)
		(We have all size of 37mm shim from 2.35mm to
		3.30mm thickness with 0.05mm thickness interval.)
FTL-937D-17	13753-54490	SHIM, LIFTER (37XT=3.25)
FTL-937D-09	13753-54410	- DO - (37XT=3.30)
FTH-937G-01	13753-64010	SHIM, LIFTER (34XT=2.20) 1FZ
FTH-937G-02	13753-64030	- DO - (34XT=2.25)
		(We have all size of 34mm shim from 2.20mm to
		3.40mm thickness with 0.05mm thickness interval.)
FTH-937G-24	13753-64470	SHIM, LIFTER (34XT=3.35)
FTH-937G-25	13753-64490	- DO - (34XT=3.40)
FTL-923D	13801-35010	SHAFT ROCKER
FDH-07	13801-87702	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-923	13811-56010/20	ARM SUB ASSY, V/ROCKER
FTL-923A	13811-61021	- DO - (13811-61H00)
FTL-923B	13811-61030	- DO -
FTL-923C	13811-68010	- DO - (13811-68H00)
FTH-924B	13901-38010/11	SHAFT, V/ROCKER (13911-35010)
FTL-924G	13901-38011	- DO - (13901-35010)
FTL-924A	13901-47010	- DO -
FTH-924	13901-54010	- DO - (L, ZL)
FTL-924B	13901-56010/20	- DO -
FTL-924C	13901-60021	- DO -
FTL-924E	13901-61011/20	SHAFT, V/ROCKER
FTL-924F	13901-68010	- DO -
FTL-924D	13901-60022	- DO -
FTH-924A	13901-71010	- DO - (1Y, 2Y, 3Y, 4Y)
FDH-05	13901-87702	- DO -
FTL-925	13902-60020	SHAFT, V/ROCKER
FDH-06	13902-87702	- DO -
FTH-925	13912-35010	- DO - (22R)
FTL-925A	13912-38011	- DO - (22R)
FTH-938	15121/2-38020K	GEAR SET, OIL PUMP (22R)
FTH-938A	15121/2-54010K	- DO - (L,2L)
FTH-938B	15121/2-54020K	- DO - (3L)
FTD-938A	15121/2-56030K	- DO -
FTL-938	15121/2-61011/20K	- DO - (3F)
FTD-938	15121/2-56022K	- DO - DYNA
FTD-938B	15121/2-56040K	- DO - DYNA
FTL-941	31231-60010	HUB CLUTCH BEARING
FTL-945	31231-60020/21	- DO -
FTL-942	31231-60031/40/70	- DO -
FTL-947	31231-60050	- DO -
FTL-948	31231-60060	- DO -
FTL-948A	31231-60080	- DO -
FTL-948B	31231-60100	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTH-655	33309-35030	FLANGE,COMPANION FOR FRONT
FTH-655A	33309-35040	- DO -
FTH-653B	33309-35061	- DO -
FTH-654C	33309-35080	- DO -
FTL-654	33309-60010	- DO -
FTL-655	33309-60020/21	- DO -
FTL-656	33309-60030	- DO -
FTL-655A	33309-60040/41	- DO -
FTL-655B	33309-60050/51	- DO -
FTL-654B	33309-60060	- DO -
FTL-654A	33309-60070	- DO -
FTL-654C	33309-60090	- DO -
FSR-101	33367-12011/12	RING SYNCHRO
FSR-101	33367-12020	- DO -
FSR-102	33367-14010	- DO -
FSR-103	33367-26021/22/23	- DO -
	33367-35010	- DO -
	33367-36030	- DO -
FSR-104	33367-40010/11	- DO -
FSR-105	33367-40012	- DO -
FSR-106	33367-55010	- DO -
FSR-201	33367-87302/09	- DO -
FSR-202	33367-87501/2	- DO -
FSR-201	33367-87601	- DO - (33367-87302)
	33367-87701	- DO -
	33367-87702	- DO -
	33368-12010/11/12	RING SYNCHRO
FSR-111	33368-20010/11/12	- DO -
	33368-32020	- DO -
FSR-112	33368-35010/11/12	- DO -
	33368-36030/40	RING SYNCHRO
FSR-210	33368-87303/4	- DO -
FSR-211	33368-87501	- DO -
FSR-120	33369-12010/11/12	RING SYNCHRO
	33369-60010	- DO -
FSR-221	33369-87302/3	- DO -
FSR-221	33369-87601	- DO - (33369-87303)

STOCK NO.	PART NO.	DESCRIPTION
FTC-963	33411-19015/16	COUNTER SHAFT
FTH-963	33411-30021	- DO -
FTL-963	33411-60020	- DO -
	33411-60030	C/GEAR, N=37-31-21. 14-14
	33435-61010	WASHER, TRANSFER
	33442-61010	WASHER, TRANSFER
FTL-701	36203-60010	GEAR SUB ASSY
FTL-702	36203-60011	- DO -
FTL-703	36203-60020/21	- DO -
FTL-704	36203-60030	- DO -
FTL-705	36203-60050	- DO -
FTL-705B	36203-60070	- DO -
FTL-705A	36203-60080	- DO -
	36203-87603	- DO -
FTL-711	36204-60010	GEAR SUB ASSY
FTL-712	36204-60011	- DO -
FTL-713	36204-60020/21	- DO -
FTL-714	36204-60030/31	- DO -
FTL-714B	36204-60070	- DO -
FTL-714A	36204-60080/81	- DO -
FTL-714C	36204-60090	- DO -
FTL-671	36209-60010	SHAFT, TRANSFER OUTPUT
FTL-671A	36209-60020	- DO -
FTL-721	36212-60020	GEAR, TRANSFER INPUT
FTL-722	36212-60021	- DO -
FTL-723	36212-60030	- DO -
FTL-724	36212-60031	- DO -
FTL-725	36212-60040	- DO -
FTL-727	36212-60041	GEAR, TRANSFER INPUT
FTL-726	36212-60050	- DO -
FTL-727A	36212-60080/81	- DO -
FTL-728	36212-60090	- DO -
FTL-728A	36212-60100	- DO -
FTL-728B	36212-60110	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-731	36215-60011	GEAR, POWER TAKE OFF
FTL-732	36215-60020	- DO -
FTL-733	36215-60030	- DO -
	36217-87603	GEAR T/F LOW SP
	36217-87604/5	- DO -
	36217-87606	- DO -
	36218-87610/08	GEAR T/F HIGH SP
	36218-87611/07/09	- DO -
	36218-87612	- DO -
	36219-87601	T/F BEARING INNER
	36219-87602/3	- DO -
FTL-741	36221-60020	GEAR, TRANSFER IDLER
FTL-742	36221-60021	- DO -
FTL-743	36221-60030	- DO -
FTL-744	36221-60031	- DO -
FTL-745	36221-60040/41	- DO -
FTL-746	36221-60060	- DO -
FTL-745A	36221-60080	- DO -
FTL-745B	36221-60090	- DO -
	36221-60100	- DO -
FTL-745C	36221-60110	- DO -
FTL-745D	36221-60120	- DO -
	36221-87604	- DO -
	36221-87605	- DO -
	36221-87606	- DO -
	36221-87608	- DO -
FTL-745C	36221-60110	M/M QTY: 50 PCS. GEAR TRANSFER IDLER
FTL-745D	36221-60120	M/M QTY: 50 PCS. GEAR TRANSFER IDLER
FTL-796	36222-60010	M/M QTY: 50 PCS. WASHER, TRANSFER
FTL-796A	36222-60020	M/M QTY: 50 PCS. WASHER, TRANSFER
FTL-751	36225-60020	SHAFT, TRANSFER IDLER GEAR
FTL-752	36225-60030	- DO -
FTL-753	36225-60040	- DO -
FTL-754	36225-60050	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-761	36231-60010/11	SHAFT, TRANSFER OUTPUT
FTL-762	36231-60012	- DO -
FTL-763	36231-60020/21	- DO -
FTL-764	36231-60031	- DO -
FTL-763A	36231-60050	- DO -
	36231-87601	- DO -
	36231-87602	- DO - (36203-87601)
	36232-87603	SHAFT, TRANSFER OUTPUT
FTL-771	36234-60020/21	SHAFT, TRANSFER OUTPUT
FTL-772	36234-60022	- DO -
FTL-773	36234-60023	- DO -
FTL-774	36234-60030/31	- DO -
FTL-775	36234-60040	- DO -
	36234-87601	- DO -
	36234-87603	- DO -
FTL-781	36235-60010/11	SLEEVE, TRANS.H/L CLUTCH
FTL-782	36235-60020	- DO -
FTL-783	36235-60030	- DO -
FTL-784	36235-60040	- DO -
FTL-785	36235-60060	- DO -
FTL-791	36236-60010	SLEEVE, TRANS. FR. DRIVE
FTL-792	36236-60011	- DO -
FTL-793	36236-60030	- DO -
FTL-793A	36236-60050	- DO -
	36237-60020	HUB T/F CLUTCH
	36237-60030	- DO -
	36238-87602/03	HUB T/F HIGH LOW
FTL-705C	36241-60080	HUB T/F HIGH LOW

STOCK NO.	PART NO.	DESCRIPTION
FTL-715	36242-60120	HUB T/F HIGH LOW
FTL-715A	36242-60130	- DO -
FTH-962	36313-35020	SHAFT, T/F DRIVE SHAFT
FTH-962A	36313-35040	- DO -
FTH-962B	36313-35050	- DO -
FTL-962	36313-60031	- DO -
FTL-962A	36313-60050	- DO -
FTL-962B	36313-60070	- DO -
FTL-962C	36313-60080	- DO -
FTL-962D	36313-60090	- DO - DIRECT TYPE
FTL-962E	36313-60100	- DO - ELECTRIC TYPE
	36323-60080	BRACKET
FTH-151	37100-35200	PROP. SHAFT ASSY
FTH-152	37100-35270	- DO -
FTH-513	37100-35350	- DO -
FTH-154	37100-35380	- DO -
FTH-155	37100-35410	- DO -
FTH-156	37100-35440	- DO -
FTH-157	37100-35450	- DO -
FTH-518	37100-35500	- DO -
FTH-159	37100-35510	- DO -
FTH-150	37100-35530	- DO -
FTH-161	37100-35540	- DO -
FTH-162	37100-35600	- DO -
FTH-163	37100-35610	- DO -
FTH-164	37100-35680	- DO -
	37110-27020	PROP. SHAFT ASSY, REAR
FTH-165	37110-35200	- DO -
FTH-166	37110-35210	- DO -
FTH-167	37110-35230	- DO -
FTH-168	37110-35240/41	- DO -
FTH-169	37110-35250	- DO -
FTH-170	37110-35300	- DO -
FTH-171	37110-35390	- DO -
FTH-172	37110-35391	- DO -
FTH-173	37110-35400	- DO -
FTH-174	37110-35442	- DO -
FTH-175	37110-35451	- DO -
FTH-176	37110-35511	- DO -
FTH-177	37110-35520	- DO -
FTH-178	37110-35530	- DO -
FTL-195	37110-35580	- DO -
FTH-179	37110-35600/01	- DO -
FTH-180	37110-35680	- DO -
FTL-173	37110-36180	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-151	37110-60010/11	PROP. SHAFT ASSY, REAR
FTL-152	37110-60012/13	- DO -
FTL-153	37110-60020/21	- DO -
FTL-155	37110-60030/31	- DO -
FTL-156	37110-60041/42	- DO -
FTL-157	37110-60051/52	- DO -
FTL-158	37110-60060/61	- DO -
FTL-158A	37110-60070/71	- DO -
FTL-160	37110-60080/81	- DO -
FTL-161	37110-60090/91	- DO -
FTL-162	37110-60100	- DO -
FTL-163	37110-60110	- DO -
FTL-164	37110-60120	- DO -
FTL-177	37110-60121	- DO -
FTL-165	37110-60130	- DO -
FTL-166	37110-60140/41	- DO -
FTL-178	37110-60142	- DO -
FTL-167	37110-60150	- DO -
FTL-168	37110-60160	- DO -
FTL-169	37110-60200	- DO -
FTL-170	37110-60210	- DO -
FTL-171	37110-60220	- DO -
FTL-172	37110-60230	- DO -
FTL-174	37110-60240	- DO -
FTL-179	37110-60250	- DO -
FTL-175	37110-60260	- DO -
FTL-176	37110-60270	- DO -
FTL-181	37110-60330	- DO -
FTL-182	37110-60340	- DO -
FTL-183	37110-60350	- DO -
FTL-180	37110-60351	- DO -
FTL-184	37110-60360	- DO -
FTL-185	37110-60370	- DO -
FTL-186	37110-60380	- DO -
FTL-187	37110-60390	- DO -
FTL-184A	37110-60430	- DO -
FTL-188	37110-60440	- DO -
FTL-188A	37110-60450	- DO -
FTL-188B	37110-60460	- DO -
FTL-188C	37110-60470	- DO -
FTL-189	37110-60480	- DO -
FTL-189A	37110-60490	- DO -
FTL-186B	37110-6A250	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-190	37110-60500	- DO -
FTL-190A	37110-60510	- DO -
FTL-186A	37110-60530	- DO -
FTL-191	37110-60550	- DO -
FTL-192	37110-60570	- DO -
FTL-193	37110-60580	- DO -
FTL-194	37110-60590	- DO -
FTL-186B	37110-60590	- DO -
FTH-181	37120-35160	PROP. SHAFT ASSY, REAR
FTH-182	37120-35220	- DO -
FTH-183	37120-35280	- DO -
FTH-184	37120-35290	- DO -
FTH-185	37120-35300	- DO -
FTH-186	37120-35330	- DO -
FTH-187	37120-35340	- DO -
FTH-188	37120-35350	- DO -
FTH-189	37120-35410	- DO -
FTH-190	37120-35420	- DO -
FTH-191	37120-35440	- DO -
FTH-192	37120-35450	- DO -
FTH-193	37120-35510	- DO -
FTH-194	37120-35520	- DO -
FTH-100	37140-35013	PROP. SHAFT ASSY, FRONT
FTH-101	37140-35030	- DO -
FTH-101A	37140-35040	- DO -
FTH-101B	37140-35050/80	- DO -
FTH-101C	37140-35060	- DO -
FTH-101D	37140-35070/1	- DO -
FTL-133	37140-35190	- DO -
FTL-101	37140-60010/11	- DO -
FTL-102	37140-60012/13	- DO -
FTL-103	37140-60021/22	- DO -
FTL-104	37140-60031/32	- DO -
FTL-105	37140-60040/41	- DO -
FTL-106	37140-60050	- DO -
FTL-106	37140-60051	- DO -
FTL-107	37140-60060	- DO -
FTL-108	37140-60070	- DO -
FTL-109	37140-60080	- DO -
FTL-110	37140-60090	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-111	37140-60100	- DO -
FTL-112	37140-60120/21	- DO -
FTL-113	37140-60130/31	- DO -
FTL-114	37140-60140	- DO -
FTL-115	37140-60161	- DO -
FTL-121	37140-60170	- DO -
FTL-122	37140-60180	- DO -
FTL-115A	37140-60200	- DO -
FTL-123	37140-60210	- DO -
FTL-124	37140-60220	- DO -
FTL-125	37140-60230	- DO -
FTL-126	37140-60240/50	- DO -
FTL-127	37140-60260	- DO -
FTL-128	37140-60270	- DO -
FTL-129	37140-60280	- DO -
FTL-130	37140-60290	PROP. SHAFT ASSY, FRONT
FTL-131	37140-60300	- DO -
FTL-132	37140-60320	- DO -
FTL-131	37140-60330	- DO -
FTL-131	37140-60350	- DO -
FTL-133	37140-35190	
FTL-134	37140-60430	- DO -
FTH-503A	37230-35030	BEARING ASSY, C/SUPPORT
FTH-503	37230-35050/70	- DO -
FTH-503B	37230-35060/61/80	- DO -
FTH-503C	37230-35090	- DO -
	37230-35130	
	37301-55010	SPLINE SHAFT
	37301-55020	- DO -
	37301-55030	- DO -
FTH-211	37302-20040	SLEEVE YOKE, HIACE/KIJANG
FTH-212	37302-35010	SLEEVE YOKE
	37302-35021	- DO -
FTH-213	37302-35030	- DO -
FTL-215D	37302-35050	- DO -
FTL-215	37302-36010	- DO -
FTL-215A	37302-36020	- DO -
	37302-55030	- DO - DA110
	37302-55031	- DO - DA115

STOCK NO.	PART NO.	DESCRIPTION
FTL-212	37302-60011	- DO -
FTL-213	37302-60020	- DO -
FTL-215	37302-60030/40	- DO - 37302-36010
FTL-216A	37302-60050	- DO -
FDH-004	37302-87308/7	- DO - W/CAP
	37302-87506	- DO - S88
FDH-003	37302-87606	- DO - W/CAP
	37302-35050L	- DO - LONG
FTH-661	37304-35041	FLANGE COMPANION
	37304-36021	FLANGE COMPANION
FTL-233	37305-25010	DUST COVER
FTL-237	37305-35020	- DO -
FTL-236	37305-36020	- DO -
FTL-235	37305-60010	- DO -
	37305-35020L	- DO - LONG
	37311-55020	BALL YOKE DA110
FTL-208	37315-35060	
FTH-201	37315-20020	FLANGE, HIACE/KIJANG
FTH-201A	37315-30011	- DO -
FTH-202	37315-35010/21	- DO -
FTL-207	37315-35040	- DO -
FTH-203	37315-35050	- DO -
FTL-205	37315-36010	- DO - 37315-60030
FTL-206	37315-36020	- DO -
	37315-55030	- DO -
	37315-55031	- DO -
FTL-202	37315-60011	- DO -
FTL-203	37315-60021	- DO -
	37315-87308/7	- DO - V22H
	37315-87501/04	- DO - S38
	37315-87509	- DO - S75
	37315-87539	- DO - S88
FDH-001	37315-87601	- DO -
FDH-002	37315-87608	- DO -
FTL-551C	41101-35070/71	CARRIER SUB ASSY
FTL-551	41101-60021	- DO -
FTL-551A	41101-60040	- DO -
FTL-551D	41101-60060/61	- DO -
FTL-551B	41101-60080/81	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-557	41110-60015/16	CARRIER ASSY
FTL-556	41110-60025/26	- DO -
FTL-559	41110-60110	- DO -
FTL-561	41110-60130	- DO -
FTL-562	41110-60230	- DO -
FTL-555	41110-60906	- DO -
FTL-558	41110-60907	- DO -
FTH-573	41201-29495/536	FINAL GEAR SET
FTH-574	41201-29525/26	- DO -
FTL-575	41201-29645	- DO -
FTH-571	41201-39077/78	- DO -
FTH-572	41201-39395/96	- DO -
	41201-39447	- DO - RK#
FTH-572	41201-39696	- DO - YN67
FTL-576	41201-39705	FINAL GEAR SET
FTL-571	41201-69036	- DO -
FTL-571	41201-69038	- DO - 37:10
FTL-571	41201-69039	
FTL-572	41201-69046	- DO -
FTL-572	41201-69048	- DO - 37:9
FTL-572	41201-69049	- DO -
FTL-574	41201-69095	- DO -
FTL-573	41201-69105	- DO -
FTL-572	41201-69126	- DO - 37:9
FTL-572	41201-69127	- DO -
FTL-572	41201-69128	- DO -
FTL-571	41201-69136	- DO - 37:10
FTL-571	41201-69137	- DO -
FTL-571	41201-69138	- DO -
FTL-574A	41201-69155	- DO -
FTL-574A	41201-69155/56	- DO -
FTL-574A	41201-69156	- DO - 37:10
FTL-573A	41201-69165	- DO - 37:9
FTL-573A	41201-69165/66	- DO -
FTL-573A	41201-69166/67	- DO - 37.9 RING & PINION ONLY.
FTL-577	41201-69225	- DO -
FTL-577A	41201-69235	- DO -
FTL-577B	41201-69245	- DO -
FTL-577D	41201-69265/6	- DO - RING & PINION ONLY.
FTL-577E	41201-69325	- DO -
FTL-577F	41201-69335	- DO -
FTL-577G	41201-69345	- DO -
FTL-577H	41201-69405	- DO -
FTL-577J	41201-69435	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTH-656A	41204-26011/40	FLANGE, COMPANION
FTH-653	41204-34010	FLANGE, COMPANION
FTL-651	41204-35010/11	- DO -
FTL-652	41204-35020/21	- DO -
FTL-653B	41204-35040/80	- DO -
FTH-653A	41204-35050	- DO -
FTL-653C	41204-35082	- DO -
FTL-653D	41204-35100	- DO -
	41204-36032	- DO -
FTL-653	41204-60010	- DO -
FTL-653A-05	41204-60010/30	- DO - (8 HOLES)
FTL-653A	41204-60030/50	- DO -
FTL-581	41226-35010	BOLT, RING GEAR
FTL-598	41231-24010	SPACER
FTL-598A	41231-40010	- DO -
FTL-598B	41231-40011	- DO -
FTL-598C	41231-60020/30	- DO -
FTL-595D	41301-35010	CASE SUB ASSY (41311-35010)
	41301-36040	- DO -
FTL-595B	41301-60010/11	- DO -
FTL-595C	41301-60020/21	- DO -
FTL-595H	41301-60060	- DO -
FTL-595J	41301-60070	- DO -
FTL-595E	41302-35010	CASE SUB ASSY
FTL-595F	41302-35020	- DO -
FTL-595G	41302-60040	- DO -
FTL-595	41311-36010	CASE SUB ASSY
FTL-595A	41311-40020	- DO -
FTL-595J	41311-60060	CASE, FRONT DIFFERENTIAL
	41311-87510	- DO - S88
FTL-590	41331-25010	GEAR, DIFF SIDE
FTL-591C	41331-35010/11	- DO -
FTL-591	41331-35020	- DO -
FTL-591D	41331-35030	- DO -
FTL-591E	41331-35040	- DO -

STOCK NO.	PART NO.	DESCRIPTION
	41331-36020	- DO -
	41331-36031	- DO -
FTL-591A	41331-60010	- DO -
FTL-591B	41331-60020	- DO -
	41331-87601	- DO - F#
FTL-592D	41341-25010	GEAR, DIFF PINION
FTL-592B	41341-35010	- DO -
FTL-592C	41341-35020	- DO - 41341-30052
	41341-36010	- DO -
	41341-39020	- DO -
FTL-592	41341-55010/12	- DO -
FTL-592A	41341-60010	- DO -
	41341-87302	- DO - F#
	41341-87303	- DO -
	41341-87304	- DO -
FTL-593C	41342-39610	SHAFT, DIFF PINION
FTL-593	41342-55010	- DO -
FTL-593A	41342-60010	- DO -
FTL-593B	41342-60020	- DO - NO.2
	41342-87506	- DO -
FTL-599	41343-35010	PIN PINION SHAFT
FTL-599	41343-55010	- DO -
FTL-596D	41351-30051	M/M QTY: 50 PCS. WASHER DIFF PINION0.9MM
FTL-596B	41351-30052	M/M QTY: 50 PCS. WASHER DIFF PINION0.5MM
FTL-596C	41351-30060	
FTL-596	41351-35010/11	MIM QTY: 50 PCS. WASHER DIFF PINION
FTL-596A	41351-60010	MIM QTY: 50 PCS. WASHER DIFF PINION
FTL-597B	41361-24010	M/M QTY: 50 PCS. WASHER, DIFF SIDE
FTL-597	41361-35010	M/M QTY: 50 PCS. WASHER, DIFF SIDE (-60010)
FTL-597A	41361-40020/21	M/M QTY: 50 PCS. WASHER, DIFF SIDE
FTL-597A	41361-60020	M/M QTY: 50 PCS. WASHER, DIFF SIDE
FTL-597C2	41361-60040	M/M QTY: 50 PCS. WASHER, DIFF SIDE

STOCK NO.	PART NO.	DESCRIPTION
FTL-611	42311-60021/22	SHAFT RH, REAR AXLE
FTL-613	42311-60051	- DO -
FTL-615	42311-60052/53	- DO -
FTL-611	42311-60060/61	- DO -
FTL-619	42311-60062	- DO -
FTL-617	42311-60070/71	- DO -
FTL-615A	42311-60080	- DO -
FTL-612	42312-60011/12	SHAFT LH, REAR AXLE
FTL-614	42312-60041	- DO -
FTL-616	42312-60042/43	- DO -
	42312-60070/71	- DO -
FTL-620	42312-60072	- DO -
FTL-618	42312-60100/1	- DO -
FTL-395B	42323-60010	M/M QTY: 100 PCS. CONE WASHER
FTL-631	42325-55010	M/M QTY: 100 PCS. LOCK, REAR AXLE SHAFT
FTL-621B	42401-60010	HUB, REAR (W/OUT BEARING)
FTL-621C	42401-69015	- DO - (W/BEARING)
FTL-621	42411-60011	HUB, REAR (163 M/M)
FTL-621A	42411-60030	- DO -
FTL-625	42420-60140	HUB & BRAKE DRUM, REAR AXLE
FTK-102	42423-20010	RETAINER (W/BEARING)
FTL-632	42427-60020/21	NUT REAR AXLE
FTL-632K	42427-60021K	LOCK NUT KIT
FTL-633	42428-60011	PLATE REAR AXLE
FTL-635	42431-60070	DRUM SUB-ASSY, REAR BRAKE W/PIN
FTL-301	43204-60020	M/M QTY: 30 KITS FR. AXLE SEAL KIT
FTL-301A	43204-60030/31	M/M QTY: 30 KITS FR. AXLE SEAL KIT
FTL-301B	43204-60040	M/M QTY: 30 KITS FR. AXLE SEAL KIT
FTL-345A	43211-35050	STG. KNUCKLE RH
FTL-347A	43211-35090	- DO -
FTL-345	43211-60020/21	- DO -
FTL-345	43211-60024/40	- DO -
FTL-347	43211-60032	- DO - DISK BRAKE
	43211-60050	- DO -
FTL-347B	43211-60060	- DO -
FTL-345B	43211-60070	- DO -
FTL-347C	43211-60090	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-346A	43212-35020	STG. KNUCKLE LH
FTL-348A	43212-35050	- DO -
FTL-346	43212-60020/21	- DO -
FTL-346	43212-60024/40	- DO -
FTL-348	43212-60032	- DO - DISK BRAKE
	43212-60050	- DO -
FTL-348B	43212-60060	- DO -
FTL-346B	43212-60070	- DO -
FTL-348C	43212-60090	- DO -
FTL-331	43232-60020	KNUCKLE CAP
FTL-332	43232-60021/35010	- DO -
FTL-332A	43232-60030	- DO -
FTL-312	43401-60012/60	FRONT KNUCKLE SPINDLE
FTL-313	43401-60040/1	- DO -
	43401-87601	- DO - F#
	43401-87604	- DO -
FTL-313A	43401-60080	FRONT, SPINDLE W/NEEDLE
FTL-606	43405-60013/14	SHAFT DRIVE OUTER
FTL-607	43405-60015/16	- DO - OUTER
FTL-607A	43405-60030	- DO - OUTER
FTL-607B	43405-60040	- DO - OUTER
FTL-608A	43410-60050	SHAFT ASSY, FRONT DRIVE, RH
FTH-601	43411-35010	SHAFT FR.AXLE INNER RH 389M/M
FTL-601	43411-60020/60	- DO - INNER RH 440M/M
FTL-601A	43411-60030	- DO - INNER RH
FTL-601B	43411-60040/90	- DO - INNER RH 455M/M
FTL-601C	43411-60070	- DO - INNER RH 415M/M
FTL-601D	43411-60100	- DO - INNER RH 420 M/M
FTH-602	43412-35010	SHAFT FR.AXLE INNER LH 799M/M
FTL-602	43412-60020/90	- DO - INNER LH 740M/M
FTL-602A	43412-60030	- DO - INNER LH
FTL-602B	43412-60070	- DO - INNER LH
FTL-602C	43412-60100	- DO - INNER LH 770M/M
FTL-602E	43412-60110	- DO - INNER LH 868M/M
FTL-602D	43412-60120	- DO - INNER LH 774M/M
FTL-609A	43420-60090	SHAFT ASSY, FRONT DRIVE, LH

STOCK NO.	PART NO.	DESCRIPTION
FTH-358	43421-35010	FLANGE, AXLE SHAFT
FTL-385	43421-60010	- DO -
FTL-386	43421-60012	- DO -
FTL-387	43421-60013	- DO -
FTL-387A	43421-60020/1	- DO -
FTL-387B	43421-60030	- DO -
FTL-387D	43421-60040	- DO -
FTL-391	43423-60010	M/M QTY: 50 PCS. CAP HUB
FTL-393	43423-60011	M/M QTY: 50 PCS. CAP HUB (43423-35010)
FTH-351	43502-35020	FRONT AXLE HUB
FTH-352A	43502-39015	- DO - DISK BRAKE
FTH-352	43502-39025	- DO - DISK BRAKE
FTL-351	43502-60020	- DO - DISK BRAKE (43502-39095)
FTL-352B	43502-60040	- DO - DISK BRAKE
FTL-352C	43502-60060	- DO - DRUM BRAKE(43502-69065)
FTL-352D	43502-60070	- DO - (43502-69025)
FTL-397	43510-60150	HUB & BRAKE DRUM ASSY, FRONT AXLE
FTH-352B	43511-35904	FRONT AXLE HUB
FTH-352C	43511-35905	- DO -
FTL-352	43511-60012	- DO - (117M/M)
FTL-352A	43511-60013	- DO -
	43512-60030/70	DRUM, BRAKE
FTL-373	43521-60010	M/M QTY: 50 PCS. NUT, ADJUSTING
FTL-373K	43521-60010K	M/M QTY: 50 PCS. ADJTNG. NUT WASHER KIT
FTL-374	43521-60011	M/M QTY: 50 PCS. NUT, ADJUSTING
FTL-374K	43521-60011K	M/M QTY: 50 PCS. ADJTNG. NUT WASHER KIT
FTL-381	43523-60010	M/M QTY: 50 PCS. WASHER, ADJUSTING
FTL-521	45040-69040X	END 5 PCS KIT (RHD)
FTL-522	45040-69045X	- DO - (LHD)
FTL-523	45040-69050X	END 4 PCS KIT (RHD)
FTL-524	45040-69055X	- DO - (LHD)
FTL-525	45040-69060X	- DO - (RHD)
FTL-526	45040-69065X	- DO - (LHD)
FTL-527	45040-69070X	- DO - (RHD)
FTL-528	45040-69075X	- DO - (LHD)
FTL-529	45040-69080X	- DO - (RHD)
FTL-530	45040-69085X	- DO - (LHD)
FTL-533	45040-69090X	- DO - (RHD)
FTL-534	45040-69095X	- DO - (LHD)
FTL-531	45040-69100X	- DO - (RHD)
FTL-532	45040-69105X	- DO - (LHD)
FTL-529A	45040-69081X	- DO - (RHD)

STOCK NO.	PART NO.	DESCRIPTION
FTL-509	45044-69015/45/65	END ASSY 21MM LH (RHD)
FTL-513	45044-69025/35/55	- DO - 21MM LH (LHD)
FTL-514	45044-69075	- DO - 21MM LH (RHD)
FTL-514A	45044-69076	- DO - 21MM LH (RHD)
FTL-515	45044-69085	- DO - 21MM LH (LHD)
FTL-515A	45044-69086	- DO - 21MM LH (LHD)
FTL-518	45044-69095	- DO - 21MM LH (RHD)
FTL-518A	45044-69097	END SUB ASSY
FTL-519	45044-69105	END ASSY 21MM LH (LHD)
FTL-509A	45044-69115	- DO - 21MM LH (RHD)
FTL-513A	45044-69125	- DO - 21MM LH (LHD)
FTL-501	45045-69015/10/13	END ASSY 17MM LH
FTL-510	45045-69025/35/45	- DO - 21MM RH
FTL-512A	45045-69046	- DO - 21MM RH
FTL-517	45045-69055	- DO - 21MM RH
FTL-510A	45045-69065	- DO - 21MM RH
FTH-511	45046-35080	TIE ROD END ASSY, HILUX
FTL-502	45046-69025/30/33	END ASSY 17MM RH
FTL-504	45046-69035/40/42	- DO - 21MM RH
FTL-505	45046-69045/13/71	- DO - 21MM LH (RHD)
FTL-506	45046-69055/23/81	- DO - 21MM LH (LHD)
FTL-508	45046-69065	- DO - 23MM LH (RHD)
FTL-511	45046-69075	- DO - 23MM LH (LHD)
FTL-508	45046-69105	- DO - 23MM LH (RHD) 45046-69065
FTL-511	45046-69115	- DO - 23MM LH (LHD) 45046-69075
FTL-516	45046-69125	- DO - 23MM LH
FTL-508A	45046-69135	- DO - 23MM LH
FTL-508B	45046-69145	- DO - 23MM LH (RHD)
FTL-511A	45046-69155	- DO - 23MM LH (LHD)
FTL-516A	45046-69127	
FTH-512	45047-35050	TIE ROD END ASSY, HILUX
FTL-503	45047-69025/10/13	- DO - 17MM LH
FTL-507	45047-69035/65	- DO - 23MM RH
FTL-507A	45047-69085	- DO - 23MM RH
FTL-341	45210-60070	SHAFT ASSY, STEERING MAIN
FTL-343	45222-60031	M/M QTY: 50 PCS. COVER, DUST
FTL-343A	45225-60010	M/M QTY: 50 PCS. BLOCK, BEARING

STOCK NO.	PART NO.	DESCRIPTION
FTC-001	45230-14020	COUPLING ASSY
FTH-001A	45230-27020	- DO -
FTH-001B	45230-27040	- DO -
FTC-001	45230-30100	- DO - 45230-14020
FTH-001	45230-35020	- DO -
FTH-002	45230-35040	- DO -
FTL-335	45230-36010	- DO -
FTL-335A	45230-60010	- DO -
	45231-87601	COUPLING ASSY
	45231-87602	- DO -
	45232-87602	- DO -
FTL-342	45260-60090	SHAFT ASSY, STEERING INTERMEDIAT NO.2
FTL-432K	45411-60090	ARM PITMAN LHD
FTL-432	45411-60110	- DO - RHD
FTL-432A	45411-60120	- DO - LHD
FTL-432B	45411-60190	- DO - LHD
FTL-432C	45411-60200	- DO - LHD
FTL-432D	45411-60210	- DO - LHD
FTL-432E	45411-60220	- DO - RHD
FTL-432F	45411-60230	- DO - RHD
FTL-432G	45411-60240	- DO - LHD
FTL-432H	45411-60250	- DO - RHD
FTL-432J	45411-60260	- DO - LHD
FTL-410	45421-60011	ARM RHD, STG. CENTER
FTL-411	45421-60021	ARM LHD, STG. CENTER
FTL-411A	45421-60041	- DO -
FTL-406	45422-60020	SHAFT, CENTER ARM
FTL-408	45424-60030	BRACKET, CENTER ARM
FTL-403	45424-60030A	CENTER ARM BRACKET ASSY
FTL-409	45424-60040	BRACKET, CENTER ARM
FTL-404	45424-60040A	CENTER ARM BRACKET ASSY
FTL-415	45430-60010/20	END ASSY
FTL-431	45430-60010P/21P	ARM, PITMAN
FTL-417	45430-60030	- DO -
FTL-418	45430-60040	- DO -
FTH-451	45440-35070	LINK ASSY RHD WO/BOOT
FTH-451A	45440-35070S	LINK ASSY RHD W/BOOT
FTH-453	45440-35070K	KIT, STG. DRAG LINK
FTH-452	45440-35080	LINK ASSY LHD WO/BOOT
FTH-452A	45440-35080S	LINK ASSY LHD W/BOOT
DR-1846	45440-39295	DRAG LINK ASS'Y DYNA
DR-1847	45440-39315	DRAG LINK ASS'Y DYNA
FTL-451	45440-69015/22	LINK ASSY RHD
FTL-452	45440-69025/32	- DO - LHD

STOCK NO.	PART NO.	DESCRIPTION
FTL-425	45442-60010X/11X	END, SUB ASSY
FTL-427	45442-60011K	M/M QTY: 50 PCS. KIT, END STG. DRAG LINK
FTH-451A	45447-35020	M/M QTY: 50 PCS. SEAL, DRAG LINK
FTL-461	45450-60012/15	ROD ASSY, STG. RHD
FTL-462	45450-60021	- DO - LHD
FTL-455	45450-60031	- DO - RHD
FTL-456	45450-60040	- DO - LHD
FTL-476	45450-69035/55	- DO - LHD
FTL-475A	45450-69045/65	ROD ASSY, STG. RHD
FTL-475B	45450-69075/6	- DO - RHD
FTL-476B	45450-69085/6	- DO - LHD
FTL-475C	45450-69095	- DO - RHD
FTL-476F	45450-69096	- DO -
FTL-476C	45450-69105	- DO - LHD
FTL-476G	45450-69115	- DO - RHD
FTL-476H	45450-69125	- DO - LHD
FTL-485	45451-60020	ROD, STG RELAY (21.7X774)
FTL-491	45451-60031	- DO -
FTL-486	45451-60040	- DO - (21.7X774)
FTL-492	45451-60050	- DO - (25 X705)
FTL-493	45451-60100	- DO - (27 X770)
FTL-493A	45451-60110	- DO - (25 X802)
FTL-493B	45451-60111	- DO -
FTL-493C	45451-60120	- DO - (27 X875)
FTL-465	45460-60025/31	ROD ASSY, STG.
FTL-466	45460-60035/41	- DO - LHD
FTL-468D	45460-69175	- DO - LHD
FTL-471	45460-69045	- DO - RHD
FTL-472	45460-69055	- DO - LHD
FTL-468	45460-69095	- DO - RHD
FTL-467	45460-69105	- DO - LHD
FTL-467B	45460-69115	- DO - RHD/LHD
FTL-468B	45460-69117	
FTL-467A	45460-69125	- DO - RHD
FTL-468A	45460-69135	- DO - LHD
FTL-473	45460-69155	
FTL-468C	45460-69165	- DO - RHD
FTL-495	45461-60020/21	ROD, STG TIE (25X 1075)
FTL-496	45461-60030	- DO - (29X 1130)
FTL-496B	45461-60090	- DO - (29X 1055)
FTL-496C	45461-60091	- DO -
FTL-496D	45461-60092	- DO -
FTL-496E	45461-60100	- DO - (29X 1070)
FTL-496F	45461-60110	- DO - (29X 1152)

STOCK NO.	PART NO.	DESCRIPTION
FTL-497	45466-30010	M/M QTY: 50 PCS. CLAMP W/BOLT NUT 21.1
FTL-498	45466-30020	M/M QTY: 50 PCS. CLAMP W/BOLT NUT
FTL-498A	45466-36010	M/M QTY: 50 PCS. CLAMP W/BOLT NUT 29.0
FTL-498B	45466-36020	M/M QTY: 50 PCS. CLAMP W/BOLT NUT 27.0
FTL-499	45466-55010	M/M QTY: 50 PCS. CLAMP W/BOLT NUT 25.0
FTL-499A	45466-55020	M/M QTY: 50 PCS. CLAMP W/BOLT NUT 25.5
	45601-35030B	M/M QTY: 50 PS. BALL KNUCKLE
FTH-435	45601-35070	ARM, RH STG. KNUCKLE
FTH-435A	45601-35081	- DO -
FTH-435B	45611-35120	ARM, RH STG. KNUCKLE
FTH-435C	45611-35130	- DO -
FTH-435D	45611-35140	- DO -
FTH-435E	45611-35160	- DO -
FTH-435F	45611-35170	- DO -
FTL-435	45611-60020	- DO -
FTL-436	45611-60021/22	- DO -
FTL-437	45611-60040	- DO -
FTL-438	45611-60050	- DO -
FTL-438A	45611-60051	- DO -
FTL-438C	45611-60052	- DO -
	45611-60060	- DO -
FTL-439	45611-60070	- DO - LHD
FTL-439A	45611-60080	- DO - RHD
FTL-438D	45611-60090	- DO -
FTL-438E	45611-60091	- DO -
FTH-443	45612-35120	ARM, LH STG. KNUCKLE
FTH-443A	45612-35130	- DO -
FTH-443B	45612-35140	- DO -
FTH-443C	45612-35150	- DO -
FTH-443D	45612-35180	- DO -
FTH-443E	45612-35190	- DO -
FTL-441	45612-60020	- DO -
FTL-442	45612-60021/22	- DO -
FTL-443	45612-60040	- DO -
FTL-444	45612-60050	- DO -
FTL-444A	45612-60051	- DO -
FTL-444C	45612-60052	- DO -
FTL-444B	45612-60060	- DO -
FTL-445	45612-60070	- DO - RHD
FTL-445A	45612-60080	- DO - LHD
FTL-444D	45612-60090	- DO -
FTL-444E	45612-60091	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-447	45613-60011	ARM, STG KNUCKLE NO.3 RH
FTL-448	45613-60021	- DO -
FTL-447A	45613-60030	- DO -
FTL-448A	45613-60040	- DO -
FTL-961	46501-60011	DRUM SUB ASSY PARKING BRAKE
FTL-961A	46501-60012	- DO - PARKING BRAKE
FTL-961B	46501-60030	- DO - PARKING BRAKE
FTL-961C	46501-60031	- DO - PARKING BRAKE
FTL-626R	47061-60011	ADJUSTER ASSY, SHOE, RH
FTL-626L	47062-60011	ADJUSTER ASSY, SHOE, LH
FTL--626A	47062-60020/21	- DO -
FTL-627R	47624-60010	CRANK, PARKING BRAKE NO.1
FTL-627L	47625-60010	CRANK, PARKING BRAKE NO.2
FTL-628	47633-35020	BOOT, PARKING BRAKE
FTH-419	48061-26010	BUSH
FTL-349A	48061-60010	- DO -
FTH-418	48106-26040	BUSH HIACE
FTH-403B	48106-35010	- DO -
FTH-403C	48106-35011	- DO -
FTH-403A	48167-35010	ARM TORQUE
FTH-403	48167-35020	- DO -
FTH-403D	48167-35040	- DO -
FTL-874	48403-60022	BRACKET FR. RH R/L FRONT
FTL-876	48404-60010	BRACKET FR. RH RE. SPRING
FTL-876A	48404-60020	- DO - REAR SPRING
FTL-876B	48404-60030	- DO - REAR SPRING
FTL-876C	48404-60040	BRACKET FR. R/L REAR
FTL-877	48407-60010	BRACKET FR. LH RE. SPRING
FTL-877A	48407-60020	- DO - REAR SPRING
FTL-877B	48407-60030	- DO - REAR SPRING
FTL-871E	48411-60030/31	BRACKET RR. RH/LH FR. SPRING
FTL-871	48411-60032	BRACKET RR. R/L FR. SPRING
FTL-871A	48411-60050	BRACKET FR. RH FR. SPRING
FTL-871F	48411-60060	- DO -

STOCK NO.	PART NO.	DESCRIPTION
FTL-871B	48412-60010	BRACKET FR. LH FR. SPRING
FTL-871G	48412-60030	- DO -
FTL-872	48414-60021	BRACKET FR. RH RE. SPRING
FTL-873	48415-60021	BRACKET FR. LH RE. SPRING
FTL-875	48416-60050	BRACKET RR. R/L REAR
FTL-871C	48433-60020	BRACKET RR. RH FR. SPRING
FTL-871H	48433-60030	- DO -
FTL-871D	48434-60020	BRACKET FR. LH FR. SPRING
FTL-871J	48434-60030	- DO -
FTH-413	48632-22020	BUSH, UPPER ARM MARK2
FTH-409	48632-26010	BUSH, UPPER ARM HIACE/HILUX
	48632-27010	BUSH
FTH-409A	48632-30012	- DO - HILUX
FTH-409C	48632-35010	- DO - R. R.
FTH-409D	48632-35020	- DO -
FTH-409B	48632-35050	- DO - F. R.
	48632-39025	- DO -
FTH-410	48635-26010	BUSH HIACE/HILUX
	48635-28010	- DO -
FTK-101	48654-12010	BUSH, LOWER ARM
FTH-415	48654-20060	- DO - HIACE
FTH-414	48654-22010	- DO - HIACE
FTH-414A	48654-22030	- DO - HIACE
FTH-411B	48654-30020	- DO -
FTH-414C	48654-30040	- DO -
FTH-411	48654-35010/30	- DO -
FDH-411	48654-87501	BUSH, LOWER ARM
FTH-417	48655-12010	- DO - EE90
FTH-416	48655-20030	- DO -
FTL-349B	48702-60050	BUSH
FTL-879D	48802-60050K	LINK KIT, STABILIZER (INCLUDING 2 PCS/KIT)
FTL-879	48802-60010K	LINK KIT, STABILIZER (INCLUDING 2 PCS/KIT)
FTL-879A	48802-60030K	REAR STABILIZER LINK KIT (2 PCS KIT)
FTL-879B	48802-60090K	REAR STABILIZER LINK KIT (2 PCS KIT)
FTL-879C	48822-60040K	FRONT STABILIZER LINK KIT (2 PCS KIT)
	90101-12083K	M/M QTY: 50 PCS. BOLT KIT, PROP. SHAFT

STOCK NO.	PART NO.	DESCRIPTION
FTL-241C	90105-10085K	M/M QTY: 50 PCS. BOLT KIT, PROP. SHAFT
FTL-241B	90105-11013K	M/M QTY: 50 PCS. - DO - (90179-11014K)
FTL-310A-1	90116-12007	M/M QTY: 50 PCS. BOLT STUD (12X 50)
FTL-582	90179-12134	M/M QTY: 50 PCS. NUT, RING GEAR
FTL-588	90179-20001	M/M QTY: 50 PCS. NUT, DIFF FLANGE
FTL-587	90179-20061	M/M QTY: 50 PCS. - DO -
FTL-589D	90179-22003	M/M QTY: 50 PCS. - DO -
FTL-589A	90179-22005	M/M QTY: 50 PCS. - DO -
FTL-589E	90179-22011/16	M/M QTY: 50 PCS. - DO -
FTL-589	90179-26002/1	M/M QTY: 50 PCS. - DO -
FTL-589B	90179-26004	M/M QTY: 50 PCS. - DO -
FTL-586	90201-20005	M/M QTY: 50 PCS. WASHER, DIFF FLANGE
FTL-585	90201-20329	M/M QTY: 50 PCS. - DO -
FTL-586A	90201-22007	M/M QTY: 50 PCS. - DO -
FTL-681	90201-22005	M/M QTY: 50 PCS. - DO -
FTL-795	90209-25001	M/M QTY: 50 PCS. WASHER, TRANSFER IDLER
FTL-794	90209-25006	M/M QTY: 50 PCS. - DO -
FTL-371	90214-38013	M/M QTY: 50 PCS. WASHER, CLAW
FTL-372	90214-42030	M/M QTY: 50 PCS. - DO -
FTL-382	90215-38020	M/M QTY: 50 PCS. - DO -
FTL-383	90215-42025	M/M QTY: 50 PCS. - DO -
FTL-343B	90301-60122	M/M QTY: 50 PCS. O RING
FTL-583	90311-38134	M/M QTY: 50 PCS. OIL SEAL, DIFF CARRIER
FTL-305	90313-93011	M/M QTY: 50 PCS. SEAL DUST
FTH-1005K	90341-12012K	M/M QTY: 50 PCS. PLUG SCREW W/WASHER
FTL-1005K	90341-18089K	M/M QTY: 50 PCS. - DO -
FTL-322B	90364-33011	M/M QTY: 50 PCS. BEARING NEEDLE
FTL-322A	90381-35001	M/M QTY: 50 PCS. BUSH, SPINDLE
FTL-407	90384-26102	M/M QTY: 50 PCS. BUSH, CENTER ARM
FTL-856	90385-15002	M/M QTY: 50 PCS. BUSH, FR & REAR SHACKLE
FTL-855	90385-15016	M/M QTY: 50 PCS. - DO -
FTH-855A	90385-18007	M/M QTY: 50 PCS. - DO -
FTL-859	90385-18009	M/M QTY: 50 PCS. - DO -
FTL-857	90385-18025	M/M QTY: 50 PCS. - DO -
FTH-855B	90385-18046	M/M QTY: 50 PCS. - DO -
FTL-858	90389-18002	M/M QTY: 50 PCS. - DO -
FTL-396	90520-31001	M/M QTY: 50 PCS. RING, DRIVE SHAFT SNAP
FTH-631	90520-36045	M/M QTY: 50 PCS. RING, REAR AXLE SHAFT

STOCK NO.	PART NO.	DESCRIPTION
FTL-361	90942-01007	M/M QTY: 50 PCS. HUB NUT
FTL-362	90942-01027	M/M QTY: 50 PCS. HUB NUT, CAP TYPE
FTL-362A	90942-01047	M/M QTY: 50 PCS. - DO -
FTH-361	90942-01048	M/M QTY: 50 PCS. - DO -
FTL-361A	90942-01051	M/M QTY: 50 PCS. HUB NUT
FTH-361A	90942-01059	M/M QTY: 50 PCS. HUB NUT
FTH-362	90942-01061	M/M QTY: 50 PCS. HUB NUT
FTH-361B	90942-01075	M/M QTY: 50 PCS. HUB NUT, CAP TYPE
FTL-362C	90942-01081	M/M QTY: 50 PCS. HUB NUT, ALMI WHEEL
FTL-362D	90942-01082	M/M QTY: 50 PCS. HUB NUT, CAP TYPE
FTL-362E	90942-01101	M/M QTY: 50 PCS. HUB NUT
FTL-353	90942-02013/14	M/M QTY: 50 PCS. HUB NUT
FTL-353K	90942-02013K	M/M QTY: 50 PCS. HUB BOLT & NUT SET
FTL-354	90942-02034/52	M/M QTY: 50 PCS. HUB BOLT
FTL-354K	90942-02034K	M/M QTY: 50 PCS. HUB BOLT & NUT SET
FTH-353	90942-02035	M/M QTY: 50 PCS. HUB BOLT, DISK BRAKE
FTH-353K	90942-02035K	M/M QTY: 50 PCS. HUB BOLT & NUT SET
FTL-353K-1	90942-02036K-1	M/M QTY: 50 PCS. HUB BOLT SET (01021)
FTK-353K-2	90942-02036K-2	M/M QTY: 50 PCS. HUB BOLT SET (01028)
FTH-354K	90942-02037	M/M QTY: 50 PCS. HUB BOLT HILUX
FTH-354K	90942-02037K	M/M QTY: 50 PCS. - DO -
FTH-355K	90942-02040K	M/M QTY: 50 PCS. - DO -
FTL-355	90942-02044/53	M/M QTY: 50 PCS. HUB BOLT
FTL-355K	90942-02044K	M/M QTY: 50 PCS. HUB BOLT & NUT SET
FTK-354	90942-02047K	M/M QTY: 50 PCS. HUB BLT W/CAP NT(01027)
FTH-355	90942-02049	M/M QTY: 50 PCS. HUB BOLT
FTL-354K-2	90942-02052K	M/M QTY: 50 PCS. HUB BOLT & NUT SET
FTL-355A	90942-02077	M/M QTY: 50 PCS. HUB BOLT
FTL-322	90999-70067	M/M QTY: 50 PCS. SOLID BUSH
	90999-73092	M/M QTY: 50 PCS. BUSH
	90999-73093	M/M QTY: 50 PCS. BUSH
FTH-101-5	FTH-101-55	C.V. PIN YOKE (8MM) 68.5 X 60.0
FTH-101A	FTH-101A	C.V. SUB ASSY HILUX (8MM) 68.5 X 60.0
FTH-102-5	FTH-102-55	C.V. PIN YOKE (10MM) 68.5 X 60.0
FTH-102A	FTH-102A	C.V. SUB ASSY HILUX (10MM) 68.5 X 60.0
	FTH-104-55	C.V. PIN YOKE (10MM) 70.0 X 61.4
FTH-231	FTH-231	SPLINE SHAFT (37301-35021) (37321-35021)
	FTH-231A	LONG SPLINE SHAFT
FTH-232	FTH-232	SPLINE CENTER
FTH-233	FTH-233	WELDED YOKE (37311-35040)

STOCK NO.	PART NO.	DESCRIPTION
FTL-112-5	FTL-112-50	BALL YOKE C.V.
FTL-112-5	FTL-112-51K	C.V. BALL KIT ASSY
FTL-112-5	FTL-112-53	JOINT KIT (114-2501)
FTL-112-5	FTL-112-54	DOUBLE YOKE
FTL-112-5	FTL-112-55	C.V. PIN YOKE (11MM)
FTL-112	FTL-112-55-50	DUST COVER PIN YOKE
FTL-112A	FTL-112A	C.V. SUB ASSY (11MM)
	FTL-113-55	C.V. PIN YOKE (10MM) 60.0 X 60.0
FTL-230	FTL-230	WELDED YOKE (OLD, 37311-60010)
FTL-231	FTL-231	WELDED YOKE (37311-36010)
FTL-232	FTL-232	SPLINE SHAFT (37301-36010)
FTL-232A	FTL-232A	- DO - (37301-60050)
FTL-232B	FTL-232B	- DO - (37301-36020)
FTL-310A	FTL-310A	M/M QTY: 50 PCS. STD/NT/WASHER/CN EA 2 PCS
FTL-310B	FTL-310B	M/M QTY: 50 PCS. STD/NT/WASHER/CN EA 2 PCS
FTL-395	FTL-395	M/M QTY: 50 PCS. STD/NT/WASHER/CN EA 1PC KIT
FTL-398	FTL-398	M/M QTY: 50 PCS. BOLT STUD KIT
FTL-509K	FTL-509K	M/M QTY: 50 PCS. STG. END REPAIR KIT
FTL-510K	FTL-510K	M/M QTY: 50 PCS. STG. END REP. KIT W/OUT BALL